

Stealth Watering System™

Gravity Tank (FLT-GT)



Philadelphia Scientific®
industrial battery innovation

This Gravity Tank must be installed a minimum of 5 feet above the battery surface in order for proper operation of the Death Vialing System™. PS0024



INJ-198
Tubing

FLT-071
Flow Indicator and Output
assembly



Installation:

1. The unit is shipped in one carton and is completely assembled.
2. Install 5 gallon tank at a height of at least **5 feet** above the top of the battery for the Float Valve.
3. Fill Tank with deionized water.

Operation Instructions:

1. Attach the output hose on the gravity tank to the Input/Filter Assembly on the Stealth Watering System™ on the battery. Filling will begin as soon as they are connected.
3. Once the spinner stops and all the Float Indicators are up, the battery filling is complete.
4. Disconnect the Quick-Connect to stop the flow.

NOTE

This water supply is not for use with Philadelphia Scientific Water Injector System™ or Philadelphia Scientific Watering Guns

© 2013 Philadelphia Scientific LLC. All Rights Reserved. Philadelphia Scientific and the PS logo are registered trademarks of Philadelphia Scientific. Stealth Watering System and Water Injedor System are trademarks of Philadelphia Scientific LLC. E&O.E.



Philadelphia Scientific LLC 207 Progress Drive Montgomeryville, PA 18936
P: 215.616.0390 F: 215.616.0500 www.phlsci.com